

Paddle Shift Set Up Notes

- .760" horizontal movement to shift one gear (in the most outward hole) **DO NOT EXCEED .800" IN EITHER DIRECTION**
- That actuator must not stop in the .350-.600" dead zone (for the outward hole), multiple shifts can take place
- A shift can take place at any distance above .350" and below .760" **MAKE SURE TO TRAVEL OVER .600"**
- Motec actuator PN 75101, 1.543" total travel
- Actuator rod end must be adjusted so the travel is centered in the neutral position

